

GETTING STARTED

Congratulations on the purchase of your new custom door kit!

Before you install this product, make sure to check the product for any damages or missing items. Please email our customer support if you have questions

This product has been inspected for workmanship, tested for proper functioning, operation and installation

Please read instructions carefully before attempting to install your DIY Door TRIM

Items Included

- * Colored Nails
- * 3 Jamb Pieces
- * 3 Brickmould Pieces

Tools You Will Need

- * Medium Duty Hammer
- * Measuring Tape & Pencil
- * Exterior Door-Window Caulk
- * Metal cutting shears(scissors)

Contact us; More Information; Additional Instructions

LA Metal Works, LLC; Texas & Missouri

info@brickmoldcover.com

Congratulations on the purchase of your new custom door kit!

Please Read the Directions Carefully!

We are unable to refund the product once its cut, scratched, bent & unpackaged. Measure twice Cut Once is best advice we can offer.

BrickMold Covers

Installation Instructions

Do-It-Yourself Door Trim Kit



www.BrickMoldCover.com

Step 1 -Measuring Inside of Door Frame & Cutting Jambs Covers

I. Measure the Top of Inside (A) of the door frame-Jamb, Add 1 inch to measurement. Find Trim A, measure/mark jamb piece with 1 inch added, cut jamb to measured length, cut off 1/2" piece on the wide side of trim leaving 1/2 inch tab on both ends for snug fit, make small 1/4" or less cuts to tabs to fit door jamb properly tabs overlap onto trim. The trim will fit accordingly.

II. Measure the left side of the inside (B) of the door frame. Find Trim B, measure/mark jamb piece with 1 inch added, cut jamb to measured length, cut off 1/2" piece of the wide side of trim leaving 1/2 inch tab on top trim cover ends only for snug fit, cut off small 1/4" or less pieces off the tabs to get a good snug fit. The tabs overlap onto jamb piece, the center should fit accordingly. The Narrow Side of Trim Remains

III. Measure the right side of the inside (C) of the door frame. Find Trim C, measure/mark jamb piece, cut off 1/2" piece of the wide side of trim leaving 1/2 inch tab on top end only for snug fit, cut off small 1/4" or less pieces off the tabs to get a good snug fit. The tabs overlap onto jamb piece, the center should fit accordingly. The Narrow side of Trim Remains

IV. Find Trim D, E, F. Measure & Cut the Brickmold Trim to length as described, Step 2, II & III. Then make tab cuts as described in Step 1, I. Tab cuts result with the short side of trim cut off. Install the Brickmould Trim Covers in following order, LEFT (E), RIGHT (D), AND FINALLY TOP (F), last Cover Piece.

Step 2 -Measuring Outside of the Door Frame & Cutting Brickmould Covers


I. Measure Brickmould trim on the outside of the door frame, from top to bottom then: Perform same TAB cutting methods as in STEP 1, part I, II.

II. Trim D is for The RIGHT SIDE OF DOOR. Vertical

III. Trim E is for THE LEFT SIDE OF DOOR. Vertical

IV. Trim F is for THE TOP SIDE TRIM of the door frame, Horizontal piece. **** LAST TO INSTALL **.**

TOP Brickmould Trim is same as Step 1, I, making tab cuts on both ends. The Tab cut is 2" from top edge.



Step 3 (Installation after Cutting)


I. Take Trim (A) Place it on the inside of the door frame/jamb at the top. Using Hammer & 3 nails provided, lightly nail the trim in @ Each End & Middle. Evenly Spaced

II. Take Trim (B) Place it on the inside (left side) of the door frame/jamb. Using Hammer & 3 nails provided, lightly nail the trim in @ Top, Middle & Bottom. Evenly Spaced

III. Take Trim (C) Place it on the inside (right side) of the door frame/jamb. Using Hammer & 3 nails provided, lightly nail the trim in @ Top, Middle & Bottom. Evenly Spaced

IV. Take Trim (D) (E): REPEAT same Steps & Methods 1 & 2 to install the trim on the RIGHT & LEFT of the OUTSIDE Brickmould Trim.

5. INSTALL TOP (F) BRICKMOULD TRIM LAST. FIND TRIM (F), AFTER MEASURING & CUTTING. CUT OUT 2 INCHES OFF FROM THE NARROW SIDE OF TRIM LEAVING THE PROFILE. THEN CUT A 45 DEGREE ANGLE ON BOTH SIDES OF BRICKMOULD TRIM FROM OUTSIDE UPPER EDGE TO EDGE OF NARROW TRIM FOR A FINAL CUSTOM APPEARANCE.




Final STEP is to APPLY EXTERIOR CAULKING to the edges of the sides, top, bottom & jamb-sill. Caulking is purchased separately

Jamb Trim Piece A.

After measuring & cutting. Cut off 1/2 inch off from Wide Jamb Piece leaving a 1/2 inch tab. Repeat on both sides. Top Jamb Trim Only

Jamb Trim Piece A.

After measuring & cutting. Cut off 1/2 inch off from Wide Jamb Piece leaving a 1/2 inch tab. Repeat on both sides. Top Jamb Trim Only





Jamb Trim Left Side (B) & Right Side (C)

After Measuring for proper fit & cutting. Now Cut off 1/2 inch off from Wide Jamb Piece leaving a 1/2 inch tab on Top Side of the Jambs Only. Bottom Side will require a slight angled cut for Door Threshold.

Brickmould Trim Left (E) & Right (D)

After Measuring for proper fit & cutting. Cut off 2 inches from the narrow trim side not the Wide profile side on Top of Trim Only. Straight Cuts on bottom




Top Brickmould Trim (F) ONLY.

After measuring for proper fit & cutting, cut out a 2 inch tab off from the narrow trim on both sides. Do not cut wide profile side. Then cut out a 45-degree angle from top corner to edge of tab cut.

Top Brickmould Trim (F) ONLY.


After measuring for proper fit & cutting, cut out a 2 inch tab off from the narrow trim on both sides. Do not cut wide profile side. Then cut out a 45-degree angle from top corner to edge of tab cut.



Brickmould Trim (F) is the Final piece to install. It is installed to the top of the door frame.

Measuring Vertically for Brickmould Trim Covers RIGHT (D) & LEFT (E), You Measure from Outside Brickmould Edge Down to Ground. A 2" tab cut out is required for proper fit. Bottom Cut is Straight no tabs

The BOTTOM Door JAMB Cover Trim B & C may require a slight angled/slanted cut to properly fit on bottom where the Jamb meets Sill-Threshold.





Measurement (A). OUTSIDE of Door Frame from outside Left Brickmould edge to outside Right Brickmould edge. Brickmould Trim Cover (F).

Measure Inside of Door Frame from Left Side Jamb to Right Side Jamb. That is the inside Jamb Cover (A) Measurement. Also, the Width of Door Actual Door Frame

Vertical Measurement (D). INSIDE of Door Frame Jamb FROM TOP to BOTTOM, Is for Jamb Trim Cover Pieces Left (B) & Right (C).

ADD an extra 2" to INSIDE Door Jamb Measurement to cover the Tab areas





**INSIDE OF
DOOR
FRAME &
CASING**

**DOOR JAMB
COVER**

**DOOR BRICKMOULD
COVER**


REQUIRED TO MAKE
SEVERAL CUTS TO
TRIM PIECES AND
INSTALLED WITH
FINISHING NAILS
THAT ARE INCLUDED.

EACH KIT HAS
DETAILED
INSTRUCTIONS
WITH PICTURES.

ALL KTB 36 INCH
AND 72 INCH BRICK
COVER KITS ARE
INTENDED FOR
BRICKMOLD DOOR TRIM
AND THEY DO NOT
HAVE A RETURN METAL
PART.

ALL KTB 36 & KTB 72 METAL
JAMB & BRICKMOULD COVER
TRIM KITS ARE DESIGNED FOR
DOOR FRAMES WITH BRICK
AROUND DOOR FRAME

FINAL STEP IS
TO APPLY
EXTERIOR DOOR
TRIM CAULK -
AND SEALANT



DOOR JAMB COVER

DOOR BRICKMOULD COVER

INSIDE OF DOOR FRAME & CASING


ALL KTS 36 INCH AND 72 INCH WITH SIDING COVER KITS ARE INTENDED FOR J-CHANNEL SIDING TRIM AND THEY DO HAVE A RETURN

ALL KTS 36 & KTS 72 METAL JAMB & BRICKMOULD COVER TRIM KITS ARE DESIGNED FOR DOOR FRAMES WITH VINYL SIDING AROUND DOOR FRAME

REQUIRED TO MAKE SEVERAL CUTS TO TRIM PIECES AND INSTALLED WITH FINISHING NAILS THAT ARE INCLUDED.

EACH KIT HAS DETAILED INSTRUCTIONS WITH PICTURES.

FINAL STEP IS TO APPLY EXTERIOR DOOR TRIM CAULK - AND SEALANT



KTB36

DESIGNED FOR DOOR FRAME WITH BRICK


BRICK Jamb & Brickmould Door Trim Cover Kit.

6 Pieces Total.

**2 Jamb Trim Covers 85" long &
1 Jamb Trim Cover 42" long**

**2 Brickmould Covers 85" long &
1 Brickmould Cover 42" long**

Colored Nails Provided



KTS36

DESIGNED FOR DOOR FRAME WITH SIDING

SIDING Jamb & Brickmould Door Trim Cover Kit.

6 Pieces Total.

**2 Jamb Trim Covers 85" long &
1 Jamb Trim Cover 42" long**

**2 Brickmould Covers 85" long &
1 Brickmould Cover 42" long**

Colored Nails Provided

**Complete Aluminum-Metal Brick & Siding
Jamb & Brickmould Cover Kit**

DOOR TRIM COLORS

PEBBLESTONE CLAY



DESERT SAND




EVERGREEN



DARK BRONZE




ALMOND



WICKER



GLOSS WHITE



BLACK



ROYAL BROWN



CHARCOAL GREY

